
## Wall mount and desk kit PF-WM

Wall mount and desk kit for the platform housing of the products AF 50, AF 125, AF 250, AF 500 and VirtuoSIS Link.

## **Extent of supply**


- 2 x mounting strips
- 4 x spacers
- 4 x nylon dowels (diameter 6 mm)
- 4 x flat washer M4
- 4 x oval head screw with cross recess (4 x 35)
- 4 x oval head screw with flat washer (M4 x 12)
- 4 x rubber feet
- · Short reference

### Desk installation



#### **Dimensions**


Measuring units in mm (in), not to scale!



### Safety warnings

- · Do not cover the housing.
- · Sufficient air flow must be assured.
- This device shall be installed or replaced by trained and qualified personnel only.
- · Only use recommended tools when installing the device.
- Do not place the device in areas where it may become wet or damp, and avoid dusty, humid and high temperature environments.
- If necessary, change the filter for the AF 125, AF 250 or AF 500 (bottom of the housing).

## Wall mounting



### Manufacturer's reference



For technical specifications, see the respective data sheet: For the latest software and documentation, visit: **www.commend.com** Keep this description in safe custody.


# Wand- und Tischmontage-Kit PF-WM

Wand- und Tischmontage-Kit für das Plattformgehäuse der Produkte AF 50, AF 125, AF 250, AF 500 und VirtuoSIS Link.

### Lieferumfang


- 2 x Montageplatte
- 4 x Abstandshalter
- 4 x Nylondübel (Durchmesser 6 mm)
- 4 x Beilagscheibe M4
- 4 x Linsenkopfschraube mit Kreuzschlitz (4 x 35)
- 4 x Linsenkopfschraube mit Beilagscheibe (M4 x 12)
- 4 x Gummifuß
- Beipackzettel

## **Tischmontage**



## **Abmessungen**


Maße in mm, kein Maßstab!



## Sicherheitshinweise

- Das Gehäuse darf nicht abgedeckt werden.
- · Achten Sie auf einen ausreichenden Luftfluss.
- Dieses Gerät darf nur von ausgebildetem Fachpersonal installiert oder ersetzt werden.
- Verwenden Sie für die Installation des Geräts nur die dafür vorgesehenen Werkzeuge.
- Stellen Sie das Gerät nie an Orten auf, an denen es nass oder feucht sein kann. Vermeiden Sie außerdem Standorte mit Staubbildung, hoher Luftfeuchtigkeit oder hoher Umgebungstemperatur.
- Wechseln Sie für den AF 125, AF 250 bzw. AF 500 ggf. den Filter (auf der Unterseite des Gehäuses).

## Wandmontage



### Hinweis des Herstellers



Technische Spezifikationen sind im entsprechenden Datenblatt zu finden. Die aktuellste Software und Dokumentation finden Sie unter: www.commend.com Bewahren Sie diese Beschreibung sorgfältig auf.

Type: D-BZ-PF-WM, Version: 1.2/0724

Commend International GmbH, Saalachstraße 51, A-5020 Salzburg – www.commend.com